


3.3.- CDR-8 connection diagram.

3.3.1.- For measuring current:



For earth leakage protection:

